


EV1 智享版规格参数

整车



宽 x 高 x 深

MIN: 58.4 x 87 x 105 cm
MAX: 66 x 98 x 105 cm

MIN: 23 x 34.3 x 41.2 inch
MAX: 26 x 38.7 x 41.2 inch

重量

69.9 kg / 154.1lbs¹


模块

名称	电池	后底盘	前底盘	主臂	座椅
宽 x 高 x 深	20.5 x 31 x 11 cm 8 x 12.2 x 4.3 inch	48 x 40 x 58 cm 19 x 15.7 x 23 inch	61 x 41.5 x 65 cm 24 x 16.3 x 25.6 inch	MIN: 25 x 35 x 71 cm MAX: 25 x 45 x 71 cm MIN: 9.8 x 13.8 x 28 inch MAX: 9.8 x 17.8 x 28 inch	MIN: 58 x 45.5 x 79 cm MAX: 66 x 59 x 79 cm MIN: 23 x 18 x 31.1 inch MAX: 26 x 23.2 x 31.1 inch
重量	6 kg / 13.2 lbs ¹	19.8 kg / 43.7 lbs	18.3 kg / 40.3 lbs	7.4 kg / 16.3 lbs	18.4 kg / 40.6 lbs


¹航空版电池比标准电池轻 1.7 kg (3.7 lbs)

拆卸步骤


1 长按电源键关机




2 安装屏幕及传感器保护罩




3 解锁并取下电池




4 取下坐垫并解锁座椅




5 抬起脚踏板并取下座椅




6 解锁主臂



7 取下主臂




8 分离前后底盘




若后备箱空间有限，建议将座椅模块放置于后排座椅上。请避免各零部件相互堆叠。

组装步骤


1 连接前底盘与后底盘




2 将主臂挂到底盘横杆上




3 将主臂下放到位，放平把手以锁住主臂




4 踩下脚踏板，确保主臂已锁定




5 取下坐垫并解锁座椅




6 将座椅安装至主臂



7 锁紧座椅并放置坐垫



8 插入电池并确认已锁定




行驶前请务必取下屏幕及传感器保护罩。


昂首 STRUTT

固定方式


1 驶入无障碍车辆





2 移座至乘客座位



3 将固定带钩在防倾轮结构上



4 将固定带钩在座椅下方



运输过程中请确保始终开启刹车/制动。

昂首 STRUTT